

## **ES2070 SV**

## **Eprom exchange**

## **■** Description

Software is updated regularly in the factory. As required, changes are incorporated in order to reflect new developments and requirements.


This description is for exchanging an EPROM in the control type ES2070 SV.

ATTENTION!: After the software update, the parameters will be set into manufacturer settings. You have to reprogram the controller after installing the new EPROM.

## **■** General Instructions

- Switch off the controller
- Unscrew the front plate (4 screws)
- Remove the EPROM
- Put the new EPROM in de socket

Attention: Place Eprom in correct way.



- Screw the front plate back to the housing
- Switch on the controller
- Reprogram the controller